

ERTY

RF = INDICATES ROD FOUND
⊙ = INDICATES ROD TO BE SET
SBL = INDICATES SET BACK LINE

33 - 41